WLM-0YSTER A



6

6

(%)

Setup Instructions

- 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram.
- 2. Make sure that all the corresponding numbers are correct.
- 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place.
- 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.
- 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet.

2447mm(96.3")

2811mm(110,7")

2869mm(113″)

448mm(57")

448mm(57")

- 6. To lock the frames together you can use the "S" shaped brackets they are designed tight so they lock well.
- 7. If you have a header in the kit you can fix to the top by using the clear plastic clips.

NO. Qua	27)	35) 4	909 2	84 0	(102°) 1	Fra
ntity Confi						Frame
rm NO.	05)	06 3	23	(22) (E)	(22)	
Quantity Confi	_	ယ	4	2	_	Frame
rm NO.				13	03	
Quantity Confi				1	3	Frame
m NO.						
NO. Quantity Confirm						Frame
1 NO.						
Quantity						Frame
Confirm						
NO.						
Quantity						Frame
Confirm						
NO.			40"	32"	22.6"	
Confirm						TV kit
NO.				CA500	CA900	Shippi
Confirm						ng Case
						Shipping Case accessories