## WLM-HAMMERHEAD A

(99)



## Setup Instructions

- according to the assembly diagram. 1. Take all the parts out of the bags and lay them on the ground
- 2. Make sure that all the corresponding numbers are correct.
- spring pop up on place. difficult you can slightly twist the parts together to make the locking 3. Now start pushing the pipes together until they firmly click, if
- the bottom, now close the Zipper. the printed fabric. Feed the fabric from the round edges of the frame 4. Its time to get your hands cleaned as now you are ready to handle feed only a few feet, then stand the frame up then slide the fabric to
- stand, lift the fabric panels and fit on the feet 5. You can set up the feet in the position that you want to erect the
- 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well
- 7. If you have a header in the kit you can fix to the top by using the

clear plastic clips.  Frame	lips.	Frame	Frame	Frame	Frame	Frame		TV kit	Shipping Case   accessories	accessories
08 2	84°	2	(102°) 2						CA900	2000H*2+2000C*2
11) 4	14	2	90° 4						CA500	
06 2	23	00	(R22)							
04) 2	27	ယ								
02 4	(35)	8	(E) 2							
NO. Quantity Confirm NO.	nfirm NO.	Quantity Confirm	Quantity Confirm NO. Quantity Confirm NO.	O. Quantity Confirm	NO. Quantity	Quantity Confirm NO. Quantity Confirm NO. Quantity Confirm NO.	onfirm NO.	Confirm	NO. Confirm	



