NO.	04	05		23	27			
Quanti	6	4	N	6	N	Frame	Set 1. Take accord 2. Mal 3. Nov difficu spring 5. You 5. You 5. You 5. To I the bo 5. To I they av	
Quantity Confirm						ЭР	 Setup Instructions 1. Take all the parts out of the bags and lay the according to the assembly diagram. 2. Make sure that all the corresponding numb. 3. Now start pushing the pipes together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until the bottom, now close the Zipper. 5. You can set up the feet in the position that stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use the they are designed tight so they lock well. 7. If you have a header in the kit you can fix to clear plastic clips. 	
firm NO.	35				90°		now closs of trap the fabric frames in the trap the fabric frames in the trap the trap the frames in the trap the frames in the trap the trap the frames in the trap the trap the trap the trap the trap the frames in the trap trap the trap the trap the trap the trap the trap trap the trap trap the trap trap the trap trap trap the trap trap trap trap trap trap trap trap	
	ত			(R2)	0		The piper of the state of the s	
Juantity	0	N	-	-	6	Frame	Ippes toge s cleaned fabric fro fabric fro and fit op ner you c hey lock.	
Quantity Confirm							and lay ther un arts tog om the frame and the fe an use well.	
m NO.							 Setup Instructions 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 2. Make sure that all the corresponding numbers are correct. 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place. 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame. 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well. 7. If you have a header in the kit you can fix to the top by using the clear plastic clips. 	
. Quantity						Frame	em on the given ready you want to then slide the top by	
						me	round round the lock if the lock the lock the lock the shrip round round the lock	
Confirm								
NO.								
luantity						Frame		•
Quantity Confirm								
M NO.							Stadrago	
						Frame		
Quantity Confirm						me		, J
onfirm								J
NO. C					\)
Quantity					$\left \right $	Frame		
Confirm								•
			40"	ω	22			
NO.)"	32"	22.6"	7		
Confirm						/ kit		
3				ç	Q	S		

