WLM-SCALLOP A



Setup Instructions

- 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram.
- 2. Make sure that all the corresponding numbers are correct.
- 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place.
- 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.
- 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet.
- 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well.
- 7. If you have a header in the kit you can fix to the top by using the clear plastic clips.

NO	(E)	R2	27)	35	900	
Quantity Confirr	2			4	4	Frame
n NO.		03	05	060	23	
Quantity		4	2	2	4	Frame
Confirm						(D
NO. Quantity Confirm NO. Quant						Frame
NO. Quantity C.						Frame
onfirm N						
10. Q						F
uantity	,					Frame
Confirm N						
10. Qu						Fr
antity Confirm						Frame
NO.			40"	32"	22.6"	
Confirm						TV kit
NO.				CA500	CA900	Shippi
Confirm						Shipping Case accessories

