

**Step 1.** Attach extrusions to base with smooth side facing out. Use 1 **long** knob per extrusion.



**Step 2.** Attach top to extrusions using 1 **long** knob per leg.



**Step 3.** Insert 2 front panels.

