

Step 1. Attach extrusions to base using 1 **long** knob per extrusion.



Step 2. Attach extrusions to top using 1 **long** knob per extrusion.



Step 3. Insert infill panels.

