

## PARTS



**(A)** Various Waveline Frame  
(Case, Hardware, & Graphic)



**(B)** Monitor Plate



**(C)** Monitor Brackets



**(D)** Allen Keys



**(E)** x6 Screws



**(F)** x2 Flange Screws



**(G)** x2 Thumb Screws



**(H)** Horizontal Bar



**(I)** Vertical Bar

## ASSEMBLY

**1**

**(A)**

Assemble the Waveline **(A)** frame by connecting the tubes together and set aside.

**2**

**(H)** **(I)** **(D)**

Assemble T-Bar by sliding Horizontal bar **(H)** into butterfly piece on the end of the Vertical bar **(I)**. Center and tighten with 5mm Allen Key **(D)**.

**3**

**(G)**

Attach the T-Bar to Waveline frame. (ensure it is facing front) Align the holes of the T-Bar to the underside of the top pole of the Waveline frame and screw in simultaneously from the bottom using 2 thumb screws **(G)**.

**4**

Place graphics over the display and zipper at the bottom.

**5**

**(F)** **(I)**

Attach the Monitor Plate to the Vertical Pole **(I)** with the provided flange screws **(F)** to the bracket in the Vertical Pole.

**6**

**(E)** **(C)**

Attach the Monitor Brackets **(C)** to the back of the monitor (not included) using 4 screws **(E)**.

**7**

Hang the Monitor from the Monitor Brackets **(C)** onto the Monitor Plate **(B)**.

**8**

**(C)** **(E)** **(I)**

Screw the bottom of the Monitor Bracket **(C)** in with screws **(E)**.

**9**

Enjoy.