

# Visual Merchandising (Creo™)

## Applicable Products:

Waterfalls (CRWF5)  
Waterfalls (CRWF7)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Insert puck glides into upright channel. Slide pucks to desired location (fig. A).
2. Align waterfall bracket with puck (fig. B).
3. Sandwich waterfall bracket in between upright and puck and tighten puck to secure (fig. C).

