	1							
NO. Quantity Confirm NO.	05 2	2	90° 2	35 2	E22 2	Frame	Setup Instructions 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 2. Make sure that all the corresponding numbers are correct. 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place. 4. Its time to get/your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper. 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use the "5" shaped brackets, they are designed tight so they lock well. 7. If you have a header in the kit you can fix to the top by using the clear plastic clips.	
firm NO.	37	23	17	16	clear)	Parts out the assemitive an slightly on place. pottom, no fabric Feed fabric pan frames to gned tight ips.	
Quantity Confirm	_	2	2	2	2	Frame	tions of the bag bly diagrau bly diagrau the fabric the fabric the fabric the fabric gether you so they lo in the kit y	
Confirm							n. n. neding nu parts tog parts tog from the che as no from the solution the ck well.	
NO. Q	34	clear R4)			Т	them or round ea round ea round ea rame up frame up et. the "S" s	
Quantity Confirm	<u> </u>	N				Frame	re correc re correc firmly cli firmly cli haped b haped b	
Confirm							FOLLENT CONTRACTIONS FROME FOLLENT CONTRACTIONS FROME FOLLENT CONTRACTIONS FROME FOLLENT CONTRACTIONS FROME FOLLENT CONTRACTIONS FROME FOLLENT FROME F	
NO. C								5
Quantity Confirm						Frame		
Confirm							AHORSE OTHER AFORSE STREET AFO	E
NO.								
Quantity						Frame		
Quantity Confirm)
NO.								
Quantity						Frame	Media Cable	
Quantity Confirm								
NO.			40"	32"	22.6"			
					5	A VT		2
Confirm						kit		7
			1			$ 0\rangle$		

