

Step 1. Attach extrusions to base using two **long** knobs.



Step 2. Attach v-legs to counter top using two **long** knobs.



Step 3. Install Optional infill panel. Attach counter assembly to base using two **long** knobs; attach to rear extrusions to top using two **long** knobs.

