

**Step 1.** Attach extrusions to base using 1 **long** knob per extrusion.



**Step 3.** Insert infill panels.



**Step 2.** Attach extrusions to top using 1 **long** knob per extrusion.

