

8

7

6


5

4

3

2

1




**PLEASE REFER TO LAST PAGE OF  
MANUAL FOR SEG INSTRUCTIONS**


**NOTES: UNLESS OTHERWISE SPECIFIED**

- 1. ASSEMBLY TIME: 1 HOUR WITH 1 PERSON.**
- 2. FEET MAY VARY.**


**24-60in WIDE x 61-96in H. SINGLE-SIDED FRAME**





DETAIL A  
SCALE 3 : 4





DETAIL C  
SCALE 3 : 4




DETAIL B  
SCALE 3 : 4





DETAIL D  
SCALE 3 : 4




TURN TO LOCK  
AND  
REVERSE TO UNLOCK




DETAIL E  
SCALE 3 : 4



TURN TO LOCK  
AND  
REVERSE TO UNLOCK




DETAIL F  
SCALE 3 : 4



DETAIL G  
SCALE 5 : 8

48" x 96" FREESTANDING IGNITER LIGHTBOX  
IG48X96-TV



PLEASE REFER TO LAST PAGE OF  
MANUAL FOR SEG INSTRUCTIONS



FRONT VIEW  
WITH GRAPHIC & MONITOR

SET-UP MANUAL



FINISH:	THIRD ANGLE PROJECTION		THIS DOCUMENT AND DATA DISCLOSED HEREIN OR HEREWITH IS NOT TO BE REPRODUCED, USED, OR DISCLOSED IN WHOLE OR IN PART TO ANYONE WITHOUT PERMISSION OF NIEDO GROUP, INC.	
MATERIAL:			5465 SW WESTERN AVE. BEAVERTON, OR 97005	
DIMENSIONS ARE IN MILLIMETERS			NIEDO GROUP, INC.	
TOLERANCES UNLESS OTHERWISE SPECIFIED	48" x 96" FREESTANDING IGNITER LIGHTBOX SETUP INSTRUCTION			
	SIZE B	DWG. NO.	REV -01	
	SCALE: NA		DO NOT SCALE DRAWING	SHEET 1

48" x 96" FREESTANDING IGNITER LIGHTBOX  
IG48X96-TV

IGNITER FRAME

MONITOR MOUNT

LED ARRAY STRIP

IGNITER FEET

CORNER BRACKETS

Z4400 MONITOR  
HORIZONTAL SUPPORTS  
WITH INTERLOCKS

FRAME JOINT INSERTS

FOOT MOUNTING  
HARDWARE

FINISH:	THIRD ANGLE PROJECTION	PROPERTY
MATERIAL:		THIS DOCUMENT AND DATA DISCLOSED HEREIN OR HEREWITH IS NOT TO BE REPRODUCED, USED, OR DISCLOSED IN WHOLE OR IN PART TO ANYONE WITHOUT PERMISSION OF NIEDO GROUP, INC.
DIMENSIONS ARE IN MILLIMETERS	NIEDO GROUP, INC. 5465 SW WESTERN AVE. BEAVERTON, OR 97005	
TOLERANCES UNLESS OTHERWISE SPECIFIED	48" x 96" FREESTANDING IGNITER LIGHTBOX SETUP INSTRUCTION	
SIZE B	DWG. NO.	REV. -01
SCALE: NA	DO NOT SCALE DRAWING	SHEET 1

48" x 96" FREESTANDING IGNITER LIGHTBOX  
IG48X96-TV

FRAME ASSEMBLY DETAILS

1. WITH FRAME FLAT ON THE FLOOR ASSEMBLE FRAME SIDES WITH JOINT INSERTS IN OUTSIDE CHANNELS OF FRAME AS SHOWN. TIGHTEN SETSCREWS.

2. ASSEMBLE CORNERS USING CORNER BRACKETS INSERTED INTO OUTSIDE CHANNELS OF FRAME AS SHOWN. FINGER TIGHTEN THUMB SCREWS ONLY.

3. ASSEMBLE FEET TO FRAME WITH SCREWS AND HARDWARE PROVIDED. FINGER TIGHTEN WING NUTS. STAND FRAME UP FOR MONITOR MOUNT ATTACHMENT.

FINISH:	THIRD ANGLE PROJECTION	THIS DOCUMENT AND DATA DISCLOSED HEREIN OR HEREWITH IS NOT TO BE REPRODUCED, USED, OR DISCLOSED IN WHOLE OR IN PART TO ANYONE WITHOUT PERMISSION OF NIEDO GROUP, INC.
MATERIAL:		
DIMENSIONS ARE IN MILLIMETERS		
TOLERANCES UNLESS OTHERWISE SPECIFIED		
SCALE: NA	DO NOT SCALE DRAWING	SHEET 1
SIZE B	OWG: HCL	REV -01
NIEDO GROUP, INC. 5465 SW WESTERN AVE. BEAVERTON, OR 97005		
48" x 96" FREESTANDING IGNITER LIGHTBOX SETUP INSTRUCTION		

48" x 96" FREESTANDING IGNITER LIGHTBOX  
IG48X96-TV

4. LOOSEN FINGER TIGHT CORNER BRACKETS ON TOP FRAME. SLIGHTLY SPREAD APART SIDES OF FRAME JUST ENOUGH TO ALLOW INTERLOCKS TO FULLY INSERT INTO FRONT CHANNEL OF FRAME AS SHOWN IN DETAIL A. TIGHTEN THE 4 INTERLOCKS SECURELY, THEN CLOSE FRAME AT TOP CORNERS AND FINGER TIGHTEN THUMB SCREWS.

FRONT CHANNEL

MONITOR MOUNT ATTACHMENT DETAIL

DETAIL A

Z4400 EXTRUSION INTERLOCK. TURN TO TIGHTEN, REVERSE TO LOOSEN.

INTERLOCKS INSERT INTO FRONT CHANNEL OF FRAME AS SHOWN

FINISH:	THIRD ANGLE PROJECTION	PROPRIETARY
MATERIAL:		THIS DOCUMENT AND DATA DISCLOSED HEREIN OR HEREWITH IS NOT TO BE REPRODUCED, USED, OR DISCLOSED IN WHOLE OR IN PART TO ANYONE WITHOUT PERMISSION OF NIEDO GROUP, INC.
DIMENSIONS ARE IN MILLIMETERS		
TOLERANCES UNLESS OTHERWISE SPECIFIED		
SIZE B	OWG, INC.	REV -01
SCALE: NA	DO NOT SCALE DRAWING	SHEET 1


NIEDO GROUP, INC.

5465 SW WESTERN AVE.  
BEAVERTON, OR 97005

48" x 96" FREESTANDING IGNITER LIGHTBOX  
SETUP INSTRUCTION

48" x 96" FREESTANDING IGNITER LIGHTBOX  
IG48X96-TV

LED ARRAY INTERCONNECT DETAIL



FINISH:	THIRD ANGLE PROJECTION	PROPRIETARY
MATERIAL:		THIS DOCUMENT AND DATA DISCLOSED HEREIN OR HEREWITH IS NOT TO BE REPRODUCED, USED, OR DISCLOSED IN WHOLE OR IN PART TO ANYONE WITHOUT PERMISSION OF NIEDO GROUP, INC.
DIMENSIONS ARE IN MILLIMETERS	NIEDO GROUP, INC. 5465 SW WESTERN AVE. BEAVERTON, OR 97005	
TOLERANCES UNLESS OTHERWISE SPECIFIED	48" x 96" FREESTANDING IGNITER LIGHTBOX SETUP INSTRUCTION	
SIZE B	DWG. NO.	REV -01
SCALE: NA	DO NOT SCALE DRAWING	SHEET 1

# Silicone Edge Graphics (SEG)

## Installation Instructions into hardware

### What are Silicone Edge Graphics (SEG)?

SEG are dye-sublimation fabric graphics with silicone strips sewn along the underside of the fabrics edge. SEG frames have grooves along their perimeter designed to snugly hold the silicone strips so the fabric can be stretched across the frame for a drum-tight fit.



We recommend laying the frame on the floor, then draping the fabric graphic on top.

The following procedure ensures the silicone edge will be place evenly over the entire frame and NOT STRETCH or GROW at the corners. Once all the edges have been secured, you should have a taut fit with a smooth flat finish.

#### 1: With Clean Hands,


Press SEG silicone edge first, into the corners of the frame.



#### 2: Working in Centers.

Go back and press the silicone edge into the center - on eachside of the frame.

EXAMPLE: A 20"x20" fabric/frame would be pressed in 8 locations.





Cont'd.

#### 3: Working in Centers again,

Go back and press the silicone edge once again on each side previous center, on all 4 sides.

Repeat this process, (WORKING IN CENTERS) until the SEG fabric's edge is pressed aproximately every 6 inches apart.

EXAMPLE: A 8' x 8' frame (using this procedure) will have been pressed/tucked 15 times (not including corners) on each side of the frame.



#### 4: After all has been pressed into your frame using

this procedure, lightly tap your forefinger to smooth fabric between the tucks.



### CARE INSTRUCTIONS

Due to the fine quality, smoothness and weave of the fabric, great care must be taken to extend the life of your SEG fabric graphics.

We recommend very loosely folding your graphic, making sure there are no hard creases or folds or that the fabric doesn't catch on sharp obects.

Store in a clean bag.  
A plastic bag or pillow case is ideal.  
Graphics can also be spot cleaned with a damp cloth.

To wash entire graphic, use a commercial size front loading washing machine on gentle cycle with cool water. Do NOT dry clean.

You can also gently iron the back side using the Polyester setting of your iron.

