


Product Parts


- 1 - Support Pole w/ Hub (x1) 1
- 2 - Hooked Poles (x4) 2



Display Set-Up


Step 1

Remove all parts from the bag and place on a clean flat surface. Insert 2 of the Hooked Poles (2) into the lower receptacles of the Support Pole w/ Hub (1) creating a tripod.




Step 2

Insert the other two Hooked Arms (2) into the top receptacles of the Hub, creating an "X".




Step 3

Attach banner by inserting the hooks located on the Top Hooked Poles (2) into the top grommets of the banner. Gently pull the banner down to hook the lower banner grommets to the lower Hooked Arms (2).



Note:

The Euro X Banner Display is designed to bend. When properly installed, the Banner will pull taut and the Hooked Arms will arch. However, if a banner smaller than the recommended size is installed, it may cause permanent failure of the display.



Storage

Place all product parts into Drawstring Pouch and store in a cool dry location.



Care

To clean, wipe with damp cloth.