

1. Put case flat on the floor and undo straps



2. Lift lid and remove the content of the case.



3. Put the lid (not the side with wheels) on the floor first. Place the supplied vertical support poles in place firmly.




4. Now lift the base and place on top of the support pole, fit the poles same as the base.



5. Place case in a clean area to fit the fabric print, like putting your pants on, start at the base, make sure zipper is in the middle.



6. Make sure that all wrinkles are out and the fabric looks straight.



6. Put the lid right on top and press to secure.



7. The zipper on the back is used to access storage.



8. Enjoy