


Eurofit Viper

Product Parts

- 1 - Bottom Front Poles (x2)
- 2 - Corner Poles (x4)
- 3 - Bottom Back Poles (x2)
- 4 - Shock-Corded Side Poles (x2)
- 5 - Top & Bottom Middle Poles (x2)
- 6 - Shock-Corded Support Bars (x3)
- 7 - Graphic



Display Set-Up

Step 1

Begin by removing all parts from the carry case and place on a clean, flat surface. Ensure you have all the components listed above.


Step 2

Assemble all poles together by connecting the corresponding number together while pressing the snap button as shown. Horizontal Support Bars (6) should be threaded in after all poles are connected.




Step 3

Display should look like the illustration below once all poles are connected with their corresponding number.




Front View



Side View

Step 4

Slightly tilt the display forward. Starting at top of frame, work the graphic (7) down to back of frame and fasten zipper.



Storage & Care

Place all product parts into Carry Case and store in a cool dry location. Recommended for indoor use only. Machine wash on gentle cycle using mild detergent. Tumble Dry No Heat. Do NOT dry clean, Do NOT Iron.