

Instructions For:

Free Standing Sign Holder - 24"



Product Specifications

Visible Graphic: 24" W x 44" H

Total Graphic Print Size: 24" W x 48" H

Foot Print Dimensions: 24" W x 10" D

Product Parts

- 1 - Feet (x2)
- 2 - Wing Nuts (x4, 2 spare)
- 3 - Screws (x4, 2 spare)




Step 1

Take all parts out of the box.


Step 2

Locate the holes on the Feet (1). Place the Feet (1) together with the holes facing one another. Together, stand the Feet (1) on their sides so you are looking at the underside.




Step 3

Lay the Graphic on its side, and place the bottom of the Graphic in between the Feet (1). Line-up the bottoms of the Feet (1) and the Graphic. Mark the holes with a pen or marker. Remove the Graphic, and pre-drill holes for the Screws (3).



Step 4

Place the Graphic back in between the Feet (1), insert the Screws (3) into the holes in the Feet (1) and Graphic, and secure them with the Wing Nuts (2).



Step 5

Stand the assembled unit upright and place in desired location.

