

# Inflatable Chair

## Product Parts

- 1 - Inflatable Chair
- 2 - Graphic
- 3 - Electric Blower (optional)
- 4 - Hand Pump (optional)



## OPTIONAL ACCESSORIES



#211013


#211014



## Display Set-Up


### Step 1

With the opening of the Graphic (2) facing you, insert the deflated Inflatable Chair (1) into the Graphic (2) by keeping the air intake valve on the right side of the Graphic (2) opening.



### Step 3

Close the Intake Valve on the Inflatable Chair (1).



### Step 2

Insert the Optional Blower or Pump's (3/4) hose into the intake valve of the Inflatable Chair (1) and begin to inflate until about 2/3 full.

**\* DO NOT FULLY INFLATE AT THIS TIME.**

Adjust the seams of the Graphic (2) to align to the seams of the Inflatable Chair (1). Once aligned, continue to inflate until Graphic (2) is tight to the Inflatable Chair (1).

**\* DO NOT OVER INFLATE THE CHAIR AS THIS MAY CAUSE DAMAGE.**

