READY POP MEDIUM STRAIGHT

READY POP FABRIC POP UP DISPLAY

PRODUCT CODE: RP3x3STR
















150w Halogen lights **UL** Listed (Optional)





Half Hard Case is optional.



*Package includes padded nylon travel bag

PRODUCT DESCRIPTION

Our ultra lightweight aluminum alloy fabric pop-up display in a matte satin anodized finish is an ideal eye-catcher for your trade show, exhibition, or conference. It's versatility and simple 2-minute setup, as well as it's Velcro attachment, makes it functional for special events as well as an in-office promotional tool for walk-in customers. Another convenient feature is that your graphic stays attached in your free travel/carry bag that comes with each frame you purchase.

DISPLAY DIMENSIONS	89"W x 89"H x 12"D
---------------------------	--------------------

GRAPHIC SIZE | 112.6"W x 88.75"H

GRAPHIC MATERIAL

Stretch Fabric

GRAPHIC FINISHING

2" Loop Velcro on back perimeter

DISPLAY CONSTRUCTION

Aluminum frame, 2" Velcro (hook) strips, and plastic hooks.

SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	36 lbs (stand only) 38 lbs (frame and graphic)
Shipping Dimensions	36"L x 16"W x 15"H

LARGE QUANTITY FREIGHT

Freight Shipping	8 boxes per 48"L x 40"W x 73"H skid
Freight Weight	333 lbs (frame only) 349 lbs (frame & graphic)

GRAPHIC TURN AROUND TIME

2 business days after proof approval

AVAILABLE ACCESSORIES

150w Halogen lights - UL Listed

Half Hard Case

AVAILABILITY CA and PA

PARTS LIST



(Qty 1) Frame (with pre-installed graphic)



(Qty 1) Padded nylon travel bag

SET UP INSTRUCTIONS








Remove frame and graphic from nylon bag.



Ensure "adjustable feet" of frame are on the floor. Pull up display into upright position.



Lock all hooks between front and back hubs.



Adjust leveling feet for desired angle. Ready pop display can now easily be moved into position.




OPTIONAL

Attach lights to top of frame by sliding the plastic "x blocks" under the frames cross sections.

Warning: To avoid damage, separate end caps & disconnect ALL hooks before collapsing the frame.

How to install or replace graphics on your OneFabric:



Remove existing graphic.



Assemble frame and lay flat on its back. Starting at one corner, attach velcro on the graphic to velcro on the frame. NOTE: Velcro on the graphic should extend approx. 1/4" - 1/2" beyond velcro on the frame (it should not be flush).



Working in a continuous direction around the frame, attach the rest of the graphic. Make sure the graphic is pulled taut while attaching the velcro.



If needed, adjust velcro for taut fit.